



ATD-3441

VACUUM PUMP - 1.5 CFM SINGLE STAGE

As a specialized enterprise in making vacuum pumps, we are always devoting ourselves to satisfying users' need of high-qualified products. We adopt the latest design and technique to make sure that our products use less energy, produce less noise and last long, but also are the best design for protecting the environment and emitting less pollution. Our excellent design and manufacturing will bring you more convenience.

1. Pump Use

ATD vacuum pumps are designed to obtain vacuum by pumping gas from sealed containers. They are suitable for use with R12, R22 and R134a air conditioning systems, as well as medical appliances, printing machinery and vacuum packing. They can be continuously used at 23°F (-5°C) to 140°F (60°C).

2. Features

Oil Anti-flow back Design

The gas inlet is specially designed to prevent the oil from flowing back, preventing the container being pumped as well as the hoses from becoming contaminated.

Environmental Design

The tank has separating devices at the exhaust port to prevent oil spraying and to reduce pollution.

Aluminum Alloy Casing

The ATD vacuum pump is manufactured with an aluminum alloy casing. Because aluminum has good heat dissipation qualities, it will help to keep the pump running more efficiently for a longer period of time.

Overall Design

The electric components and the pump are designed to make the product compact and lighter.


Easy to start, Faster to pump

The starter design makes the ATD vacuum pump easy to start even in lower temperatures. This feature allows higher efficiency and faster pumping.

Low Noise and Vibration

An electrometric-coupling insert between the motor and module results in extremely quiet and smooth operation.

3. Product Illustration



4. User's Manual

- Examine the oil-level before using to make sure the oil-level is not lower than the oil-level line in the sight glass. **DO NOT RUN PUMP WITH LOW OIL LEVELS.** Add oil to bring it up to the oil level line. This pump uses pump oil HFV-46 or equivalent.
- Connect the container to be pumped to the gas inlet. The hose should be short, sealed and free of dust, dirt and heavy condensation. Check for leaks before operating pump.
- Take off the exhaust cap, plug in the power supply and turn the switch to the on position.
- Unplug the vacuum pump, remove the connecting hoses and cover the exhaust cap and oil plug after using.

5. Cautions

- Don't pump flammable, explosive or poisonous gases.
- Don't pump gas that can corrode metals and exert chemical charges.
- Don't pump gas containing any dust or moisture.
- The temperature of the pumped gas shouldn't be over 173°F (80°C) and the room temperature should be around 23°F (-5°C) to 140°F (60°C).
- Don't use vacuum pump as a compression pump.

- Pump cannot be operated without oil
- The operating voltage is between 110V to 115V, 60Hz. You must use a grounded outlet.
- When unplugging the pump, pull the plug. Don't unplug unit by pulling on the wire.
- Keep electrical cord free from all shop equipment, and do not let pump hang by power cord
- Don't use damaged plug or outlet.
- Don't plug or pull out the plug with wet hands.
- Don't plug unit in, unplug unit or use switch if there are any flammable or explosive gases present.
- Always Unplug unit before disassembling.

6. Installation

- When in use, the pump should be horizontal and should be positioned where it is dry, ventilated and free of dust and other contaminants.
- In order to ensure proper air flow, you must maintain a clearance around the pump of at least 10 cm (4 inches)
- To permanently mount the vacuum pump, remove the rubber pads from the bottom of the base, and use the existing threaded holes to mount unit. Mount with ST4.2 screws. When permanently mounting this pump, be sure to maintain proper clearances around the unit, especially at the air intake in the end of the vane shell.
- If a special electromagnetic valve is needed, it can be installed on the gas inlet

7. Troubleshooting

Problem	Possible Cause	Correction
Low Degree of Vacuum	<ol style="list-style-type: none">1. Lack of oil2. Oil is not clean3. The oil inlet is blocked4. The hoses or gas inlet are clogged5. The pump is not suitable for your application	<ol style="list-style-type: none">1. Add oil to above the oil level line2. Change the oil3. Clean the oil inlet or clean the filter4. Check the connecting pipes5. Get suitable pump for your application
Oil Leaks	<ol style="list-style-type: none">1. The oil seal is damaged2. The housing gasket is loose or worn out	<ol style="list-style-type: none">1. Change oil seal2. Change the housing gasket
Oil Spray	<ol style="list-style-type: none">1. Too much oil2. The pressure at the gas inlet is too high or it has pumped too much	<ol style="list-style-type: none">1. Oil to the oil-level line2. Change to a bigger pump
Starting Difficulty	<ol style="list-style-type: none">1. The oil temperature is too low2. Electrical malfunction3. Foreign matter is in the pump	<ol style="list-style-type: none">1. Start the pump several times to try to heat the oil2. Check and have it fixed3. Check and remove it

8. Maintenance

- Keep the pump clean and prevent foreign matter from entering.
- Keep the oil filled to the full level. **Don't let pump run without oil.**
- Keep the oil clean. If the oil becomes dirty, muddy, or water or other volatile substance gets in, it will affect the performance of the pump and the oil should be replaced. Before replacing the oil, start the pump and have it run for about 30 minutes to make the oil thin. Stop the pump and drain the oil from the oil drain plug. At this time, open the gas inlet to release any pressure inside the pump. This will allow the oil to drain more freely. After making sure the pump is clean, put the drain plug back in and then fill the pump oil to the oil-level.
- To store the pump when not in use for long periods of time, cover the oil cap and exhaust cap and store it in a dry place.
- Repair of pump should only be done by experienced repair facilities.**

9. Technical Specifications

Model: ATD-3441

Model Power Supply: 110V 60HZ

Free Air Displacement: 1.5 CFM

Number of Stages: 1 Stage

Ultimate Vacuum: 30 Micron


Rotating Speed: 1720 r/Min

Motor: 1/6 HP

Weight: 7.2 KGS



ATD-3441



ITEM#	ORDERING PART#	PART DESCRIPTION
1	PRT3441-01	FAN COVER
2	PRT3441-02	LONG SCREW
3	PRT3441-03	SCREW
4	PRT3441-04	FAN
5	PRT3441-05	MOTOR COVER
6	PRT3441-06	CENTRIFUGAL
7	PRT3441-07	SCREW
8	PRT3441-08	ROTOR
9	PRT3441-09	POWER CABLE
10	PRT3441-10	BEARING
11	PRT3441-11	WAVEFORM GASKET
12	PRT3441-12	INSULATING BUSHING
13	PRT3441-13	SWITCH
14	PRT3441-14	STATOR
15	PRT3441-15	HANDLE COVER
16	PRT3441-16	SCREW
17	PRT3441-17	CAPACITOR
18	PRT3441-18	MOTOR COVER
19	PRT3441-19	HANDLE
20	PRT3441-20	NUT
21	PRT3441-21	OIL FILLING PORT
22	PRT3441-22	O-RING
23	PRT3441-23	INLET FITTING
24	PRT3441-24	BRACKET

ITEM#	ORDERING PART#	PART DESCRIPTION
25	PRT3441-25	OIL SEAL
26	PRT3441-26	ROTARY-VANE
27	PRT3441-27	SPRING
28	PRT3441-28	PUMP ROTOR
29	PRT3441-29	PUMP BODY
30	PRT3441-30	SCREW
31	PRT3441-31	BACK-PUMP COVER
32	PRT3441-32	CAP BOARD
33	PRT3441-33	OIL GAS SEPARATOR
34	PRT3441-34	O-RING
35	PRT3441-35	OIL TANK
36	PRT3441-36	OIL LEVEL
37	PRT3441-37	OIL SEAL CAP
38	PRT3441-38	SEAL GASKET
39	PRT3441-39	O-RING
40	PRT3441-40	BOLT
41	PRT3441-41	RUBBER FEET
42	PRT3441-42	NUT
43	PRT3441-43	FLAT GASKET
44	PRT3441-44	SCREW
45	PRT3441-45	BASEBOARD
46	PRT3441-46	BEARING PAD
47	PRT3441-47	SCREW