

1) Locate wall mount brackets as shown in top picture

- 2) Fasten Wall mount brackets to wall, as shown using drywall screws, or whatever fastener you choose. Hollow walls may require molly anchors. Wall mounts may be lined up in a row, or placed one over the other, whatever your preference and requirements are.
- 3) Clip bolt bins onto wall mount brackets and fill bins with nuts and bolts.