

ATD-7037 & ATD-7038 Medium and Large Heavy-Duty Plastic Utility Carts Owner's Manual





ATD-7038

ATD-7037 Features:

- · Heavy duty polypropylene material
- Molded handle with storage compartments and towel bar
- 3" deep trays
- (4) 5" heavy-duty non-marring casters (2-360° swivel)

ATD-7037 Specifications:

- Cart Capacity: 500 lbs. (Evenly distributed)
- Overall: 40" L x 17" W x 33" H
- Shipping Weight: 36.60 lbs.

ATD-7038 Features:

- Heavy duty polypropylene material
- Molded handle with storage compartments and towel bar
- 3" deep trays
- (4) 5" heavy-duty non-marring casters (2-360° swivel)

ATD-7038 Specifications:

- Cart Capacity: 500 lbs. (Evenly distributed)
- Overall: 46" L x 25" W x 33" H
- Shipping Weight: 50.70 lbs.

SAFETY INFORMATION

Assembly Precautions

- 1. Assemble only according to these instructions. Improper assembly can create hazards.
- 2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
- 3. Keep assembly area clean and well lit.
- 4. Keep bystanders out of the area during assembly.
- 5. Do not assemble when tired or when under the influence of drugs or medication.
- 6. Weight capacity and other product capabilities apply to properly and completely assembled product only.

User Precautions


- 1. This product is not a toy. Do not allow children to play with or near this tool cart.
- 2. Use as intended only.
- 3. Inspect before every use; do not use if parts are loose, damaged or missing.
- 4. Do not exceed listed weight capacity, evenly distributed. Be aware of dynamic loading. Sudden load movement may briefly create excess load causing product failure.
- 5. Use only on flat, level, hard surface able to properly support cart and load.
- 6. Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact your ATD Tools distributor for replacements.

Assembly Instructions

Note: Use a rubber mallet to ensure snug connection of all non-metal parts. Refer to the parts breakdown on the following page for item number references.


- 1. Place the bases of the four legs (5 & 6) into the corners of the lower tray (2). The flange on each post will only fit into specific corners.
- 2. Insert carriage bolts (10) down through the holes in the bases of the posts (5 & 6).
- 3. Attach casters (8 & 9) with carriage bolts (10) using split washers (11) and nuts (12). For best operation, the two straight casters (9) go on the one end of the cart, and the two swivel casters (8) go on the other end.
- 4. Place the upper tray (1) upside down on your work surface. Turn the handle (3) upside down with the cup holder faced toward the tray and the hand holes on the outside.
- 5. Place the tray with the handle assembly firmly on top of the legs (5 & 6). Position the handle above either the swivel or fixed casters, depending on operating preference.
- 6. Use three screws (7) through each leg (5 & 6) from underneath to secure them.





ITEM#	ORDERING PART#	PART DESCRIPTION	QTY
1	PRT7037-01	UPPER TRAY	1
2	PRT7037-02	LOWER TRAY	1
3	PRT7037-03	HANDLE	1
4	PRT7037-04	ROD	1
5	PRT7037-05	LEG (LEFT)	2
6	PRT7037-06	LEG (RIGHT)	2
7	PRT7037-HK	SCREW	12
8	PRT7037-08	SWIVEL CASTER	2
9	PRT7037-09	FIXED CASTER	2
10	PRT7037-HK	BOLT	16
11	PRT7037-HK	WASHER	16
12	PRT7037-HK	NUT	16





ITEM#	ORDERING PART#	PART DESCRIPTION	QTY
1	PRT7038-01	UPPER TRAY	1
2	PRT7038-02	LOWER TRAY	1
3	PRT7038-03	HANDLE	1
4	PRT7037-04	ROD	1
5	PRT7037-05	LEG (LEFT)	2
6	PRT7037-06	LEG (RIGHT)	2
7	PRT7037-HK	SCREW	12
8	PRT7037-08	SWIVEL CASTER	2
9	PRT7037-09	FIXED CASTER	2
10	PRT7037-HK	BOLT	16
11	PRT7037-HK	WASHER	16
12	PRT7037-HK	NUT	16



THIS WARRANTY AND CONFIRMED RECEIPT(S) SHOULD BE <u>RETAINED BY THE CUSTOMER</u> AT ALL TIMES